

— ASSEMBLY AND SAFE USE MANUAL —

BA54U, BA60U, BA72U

BACKBOARD PADDING INSTALLATION INSTRUCTIONS



Customer Service
(800) 247-7668

PARTS LIST

Item	Qty	Description	Item	Qty	Description
A	2	Pad Segments (1 LH, 1 RH)	C	1	11/64" Drill Bit
B	10	Self Drilling/Threading Screw	D	1	Installation Instruction Sheet

Tools Required:

- Portable Drill
- 5/16" Socket with Extension
- Masking Tape
- Utility Knife
- Tape Measure
- Center Punch

- ♦ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ♦ Read all instructions before proceeding.
- ♦ Save this instruction in the event that the manufacturer must be contacted in the future.

1. Check the contents of the carton for all the items listed. If an item is missing, please contact your dealer.
2. Use a tape measure to mark the center-line of the backboard. Place one of the *Pad Segments* (A) in position on the backboard. Use masking tape to hold it in position for locating mounting holes. For best fit, line up the first edge guard with the center-line and then place the second *Pad Segment* (A) next to the first.
3. Using a portable drill, a 5/16" Socket and extension, drill thread through the backboard frame and secure the *Pad Segments* (A) in place with the *Self-Drilling/Threading Screws* (B) provided. It may be necessary to use the *11/64" Drill Bit* (C) to predrill backboards with additional steel sub frame,
4. Make sure to collect all metal shavings to avoid personal injury or damage to the playing floor.

