

1000 SCHOLASTIC GOAL

Installation, operation, and Maintenance Instructions



WARNING

Failure to follow proper installation procedures can result in damage to goal and possible injury to personnel.
Read and understand all installation instructions before proceeding.

TOOLS REQUIRED:

#2 Phillips Screwdriver, 9/16" wrench, and level

INSTALLATION:

- 1) Remove goal and hardware from box and inspect for shipping damage.
- 2) Remove the four cover plate screws and cover plate.
- 3) Remove the two carriage bolts from the hardware bag along with two nuts and washers.
- 4) Install the carriage bolts through the top two goal mounting holes on the backboard, making sure the head of the bolt is on the goal side of the board. Install a washer and nut on each bolt and leave the about 1/2" of space between the board and the head of each bolt.
- 5) Slip the goal over the heads of the carriage bolts (the carriage bolt heads will fit through the large keyhole at the top of the back plate) and slide the goal down onto the bolt. The goal should be fully seated on each carriage bolt. Tighten the carriage bolt nuts enough to pull the goal firmly to the backboard.
- 6) If the backboard is a 42" glass board with two studs in the lower goal mounting position, install a washer and nut from the goal hardware bag and tighten by hand.
All other boards will require the use of the hex head bolts in the lower goal mounting holes. Install the hex bolts from the front and install a washer and nut on the backside of the board. Tighten hand tight.
- 7) Torque the stud nuts to 9 – 11 Ft.-Lbs. Torque all bolt nuts to 15 – 20 Ft.-Lbs.
- 8) Place cover plate over the goal base and secure with the 4 self-tapping screws. Make sure all four screws are tight to prevent vibration and noise from the cover.
- 9) Install the net.

MAINTENANCE:

- 1) Twice annually, remove the cover plate and spray the swing rod and bushings with penetrating lubricant. Lock-Ease® graphite spray is recommended.
- 2) Annually remove the cover plate and inspect moving components for wear, welds for cracks, and goal for overall condition.

OPERATION:

This goal has been designed and manufactured to meet NCAA and NFSHSA specifications. The goal is factory set to deflect at 90 lbs.

See reverse side for adjustment instructions.



Performance Sports Systems
9200 E. 146th Street
Noblesville, IN 46060
800-325-2682

Gared Sports
707 North 2nd St., Suite 202
St. Louis, MO 63102
800-325-2682



1000 SCHOLASTIC GOAL

Adjustment Instructions

The model 1000 goal should not require any adjustments. However, should the goal become loose or tight, the spring tension can be adjusted.

Tools Required – Phillips Screwdriver, 9/16” wrench, 7/32” Allen Wrench

1. Using a Phillips screwdriver, remove the four cover plate screws and cover plate.
2. First make sure the rim is securely tightened to the backboard. All four mounting bolts must be tight with no movement of the rim back plate to the board. If the rim bolts are loose, tighten the bolts to make sure the rim is secure and recheck.
3. Make sure the backboard is secure to the mounting structure. If the board mounting is loose, tighten the mounting bolts and retest.

The model 1000 goal is preset at the factory and should not require any further adjustments prior to installation. Adjusting the vertical springs will change the amount of pressure required to deflect the rim.

DO NOT adjust any of the spring nuts more than 1/4” from their original factory position.

4. Adjust the springs in the following sequence until the desired measurement is achieved:
 - a. Tighten or loosen the vertical springs 1/2 turn. Recheck for desired deflection pressure.
Note: Both springs must be adjusted equally. The 9/16” wrench and 7/32” Allen wrench will be required for this adjustment.
 - b. Tighten or loosen the vertical springs an additional 1/2 turn. Recheck for desired deflection pressure.
 - c. Repeat steps A and B if additional adjustment is required.

NOTE: If adjustments larger than 1/4” on any of the springs is required, contact a Gared customer service representative for assistance.

Replace the cover plate and install the four cover plate screws. Tighten the cover plate screws securely.



Performance Sports Systems
9200 E. 146th Street
Noblesville, IN 46060
800-325-2682

Gared Sports
707 North 2nd St., Suite 202
St. Louis, MO 63102
800-325-2682

